

# IP 7504 Screen Privacy Film

## Installation Recommendations and Post-Installation Care



### Installation Recommendations

- The film should be installed on the LED/LCD screen vertically or horizontally at an angle of 45° (not skewed/slanted)
- The specific direction in which the film should be applied will vary by screen technology
- We would recommend a test before installation in order to verify the correct installation direction and also to ensure that the film will function properly on the screen
- Handle the film with caution because the edges are sharp
- Pre-cut the film before installation on a flat surface (this will prevent the film from splitting)
- It must be wet applied (we would recommend a pH neutral baby shampoo)
- After installation, ensure that the edges of the film have been thoroughly dried (this will prevent the film from developing subsequent movement)
- In the event of a join being needed, a minimum 2mm gap should be left between the panels
- To prevent tunnelling, any unused film should be stored wound on its original core

### Post-Installation Care

- Do not clean for at least 1 month after application
- Do not use abrasive cleaning products, including ammonia, brushes and scrapers as these are likely to damage the surface of the film
- Do not apply any type of sticker or adhesive on the film

